

Flat-based workflow

Your workflow can start with an imposed flat (PS, PDF, EPS) created in Preps, Pandora, InDesign, or other software.

Note: The flat-based workflow fails if the AutoFlatRefining and AutoFlatOutput process templates have been deleted from the Prinergy system.

1. Create a job.
2. Add a hot folder and associate it with a refine process template.
3. In the refine process template, ensure **Treat Input Files as Flat** is selected in the Impose section.
4. Drop the file into the hot folder.
Prinergy refines the files into PDF flats and then displays flats as signatures in **Separations** view.
5. Manage colors separations (optional).
6. Proof the imposition by running an imposition output process template.
7. Make plates by running a final output process template.