

Setting a process template to use marks file

1. In any window, from the **Tools** menu, select **Process Template Editor**.
2. Open an output process template (loose page output, imposition output, or final output process template) .
3. Open the **Marks** section.
4. To place a sheet mark, click **Browse** beside the **Sheet Marks** box to locate the sheet marks PDF file.

Tip: If you are typing the path name directly in the box, use the variable %system% as part of the path name to denote the %AraxiHome%\CreoAraxi folder on your Prinergy system.

Example:

Entered in Sheet Mark box	%system%\data\MarkSets\Sheet Marks\B&W Proofer\Composite Proofs\SheetMark-BW-Comp.pdf
Resulting path name	%AraxiHome%\CreoAraxi\data\MarkSets\Sheet Marks\B&W Proofer\Composite Proofs\SheetMark-BW-Comp.pdf

5. Select the **Calibrate** check box to apply calibration curves to the marks.
The calibration curve is set in the **Calibration Curve** list in the **Calibration & Screening** section of the output process template.
6. From the **Locate Sheet Marks Adjacent to** box, select a location for the sheet marks, and then specify the distance in the **at Distance** box.
7. If you are setting the loose page process template and you want to set a page mark, click **Browse** beside the **Page Marks** box to locate the page marks PDF.
8. Select the **Calibrate** check box to apply calibration curves to the masks.
9. From the **Locate Page Marks Adjacent to** box, select a location for the page marks, and then specify the distance.
10. Save and close the process template.