

Creating an SCO in a color setup

1. Click the **Color Setups** tab, and then click the desired color setup from the list to show it in the viewer window.
2. Double-click the background to show the **Device** window.
3. Drag a device from the **Devices** window to the SCO position in the **Color Setups** viewer.
4. [Define the device condition](#) for the SCO device.
5. [Define the conversion method to be used to transform data from the SCO to the color space of the PCO.](#)