

Adding a spot ink to a print transfer curve

1. In the **Curve Channels** pane, below the **Spot Inks** table, click the **Add** button .
2. Click the **Name** column and enter the name of the spot ink, such as PANTONE 236 C.
It's important that you enter the spot ink name exactly as its separation is named in the design file, or Prinergy will not apply the correct channel.
3. Double-click the **Color** column and choose a suitable color (for visual recognition only).
4. Click **Apply**.