

Redefining a PCO profile

1. In a PCO, click the **PCO Profile** icon .
2. Click **Redefine**.
3. [Import or generate a device profile](#).