


# Redefining a new method for a SCO conversion version

You can recalculate the curves or DeviceLinks that ColorFlow has generated for a PCO to SCO conversion.

1. Click the **Color Setups** tab, and then click the desired color setup from the list to show it in the viewer window.
2. In the color setup viewer, click the **Conversion** icon  between the PCO and the SCO.
3. From the **Output Version** list, select the version that you want to redefine.
4. Click **Redefine**.
5. [Select a new conversion method](#).