

Take-off bars

Like color bars, take-off bars are tiled across the width of the substrate, stopping 0.125 in. / 3.17 mm from each edge. A take-off bar is centered horizontally on the substrate. Take-off bars can only be added to a job once, regardless of their name.

Some printers like to make shortened take-off bars to fill extra spaces. For Pandora, use a rectangle saved as a static mark.

Take-off bar	Description
TOB_Sheet.pdf	For legacy work only. Note: In the Pandora 4.0 and later software, "substrate" replaces "press sheet". Use TOB_Substrate.pdf for new work.
TOB_spot-1.pdf	Used for the first spot color in the job and set up as scaled. You can change its position in the SmartMark Settings dialog box.
TOB_spot-2.pdf	Used for the second spot color in the job and set up as scaled. You can change its position in the SmartMark Settings dialog box.
TOB_spot-3.pdf	Used for the third spot color in the job and set up as scaled. You can change its position in the SmartMark Settings dialog box.
TOB_Substrate.pdf	A mark that fills the whole substrate as a background. You must click the edge of this mark to select it. After dragging the mark into the job, you can change it to any color in the job by selecting from the Color box on the Content tab. You can also change the percentage of the color.