

Add a new Flexo standard curve to a smart hot folder workflow

1. If necessary, start Workshop.
2. From the Job Finder **Tools** menu, select **Process Template Editor**.
3. Expand the **Final Output** group.
4. Expand the **SO_BaseTemplates** group.
5. Open one of the **SO_Base_C3-xx** templates.
6. Expand the **Calibration & Screening** section of the template.
7. In the **Print Curve** list, select the curve created in Task 1.
8. From the **File** menu, select **Save As**.
9. Type a new name based on the new curve. It must follow the same naming convention that are used in the Smart Hot Folder workflow: `SO_Base_C3-xx`.
10. Select **Create Process Template**.
11. Close the process template.
12. Close the Process Template Editor.
13. You may now select the new curve in a ScreenSet or on-the-fly in the processed job.
Note: If you want to create a custom curve for the Smart Hot Folder workflow, the name of the process template must be `SO_Base_<custom name>`. You can then use the `<custom name>` when editing ScreenSets or in the job to edit screens on-the-fly.