

Changing the view

CAD Correct provides a number of ways to change the view to focus on one part of the Preview pane.

To zoom in to a part of the Preview pane use one of the following methods:


- From the **Edit** menu, select **Zoom up**.
- Press Alt and click the Preview pane.

To zoom out from a part of the Preview pane use one of the following methods:

- From the **Edit** menu, select **Zoom down**.
- Press Alt+Shift and click the Preview pane.

To change the view for the entire Preview pane:

1. From the **Edit** menu, select **Zoom to**.
2. In the dialog box, in the **New Zoom** box, enter a value.



Note: For example, if you enter 0.5, the die will appear in the Preview pane at 50 percent of its size. Any value above 50 is considered a percentage, so you can enter either 0.75 or 75 to view the die at 75 percent of its size.

3. Click **OK**.

Mirroring the file

You can mirror the input file when you plan to print on the package interior. Use one of the following methods:

- On the **Station** tab, select the **H** check box for horizontal or the **V** check box for vertical.
- On the **Die** tab, in the **Mirror** list, select **Horizontal** or **Vertical**.