


Redefining the print calibration curve target and conversion method

1. In a print calibration curve object, click the **Calibration** icon .
2. Click **Redefine**.
3. Select the the print calibration curve target and conversion method.
4. To control the spot ink channels you wish to update, click **Details** and select the spot ink channel check boxes that you want to update.
5. Save your changes.