

Methods for adding or creating new media configurations

Note: The software user documentation and help also provides much of this information.

Obtain or create the color content required to add or create a media configuration for a Matchprint Inkjet proofer and a new media type.

1. Log on to your Kodak service and support portal.
2. Determine the most suitable method for the media scenario:

Media/proofer scenario	Methods
Epson proofers (except WT7900) and media for which Kodak provides color content	<p>Go to portal answer 68827, locate and download the applicable file, and then follow the instructions for the download file type:</p> <ul style="list-style-type: none">• To import an Epson media configuration and profiles from a .ZIP file, see portal answer 68834.• To add a Matchprint media configuration and profiles directly from a .INSTALL file, see portal answer 67572.
Epson proofers (except WT7900) and media for which Kodak <i>does not</i> provide color content	<p>Create a custom media configuration. For the procedure, see portal answer 7333.</p>
WT7900 white-ink proofer and media for which Kodak provides color content	<p>Go to portal answer 60828, locate and download the applicable file, and then follow the instructions for the download file type:</p> <ul style="list-style-type: none">• To import an Epson media configuration and profiles from a .ZIP file, see portal answer 68834.• To add a Matchprint media configuration and profiles directly from a .INSTALL file, see portal answer 67572.