

About screen angles

You can specify screening angles for spot colors in the **Calibration & Screening** section of output process templates and in the Color Editor.

Prinergy searches for spot color screening information in the following order:

1. If the process template has a screening angle for the spot color, Prinergy uses the specified angle.
2. If the process template does not have a screening angle, Prinergy checks the job-specific color library. If the job-specific color library has a screening angle for this spot color, Prinergy uses it.
3. If neither the process template nor the job-specific color library has a screening angle, Prinergy checks the global color library. If the global color library has a screening angle for this spot color, Prinergy uses it.
4. If neither the process template, nor the job-specific, nor the global color library has a screening angle, Prinergy uses the default angle to screen this spot color.