

Digital Job Ticket Editor—Finishing tab

Note: Options on this tab may vary depending on the selected digital device. Some of the settings or setting values may not be available. Also, there may be additional settings available for specific devices which are not documented here.

The options in the Digital Job Ticket Editor are based on the capabilities of the selected device. When the Prinergy server connects to a digital device via Setup, the device communicates its capabilities in JMF format. The values for the different parameters are updated in the Setup application per device, and are reflected in the Digital Job Ticket Editor. The default value that was set on the digital device (and can be viewed in Setup) is used as the default value per parameter. If no value was set as default, the Job Ticket Editor displays **Device Default**. This selection can be changed.

When you define settings that are in conflict, these settings are marked with a red line around them, and when you hover above them, a tool tip displays what is wrong with the defined settings. You can also click the **Constraints** tab to see which settings you need to change in order to print the job.

Note: If you make a change in the Setup application while the Digital Job Ticket Editor is open, you must close and reopen the Digital Job Ticket Editor to see the change in the Digital Job Ticket Editor.

Output Tray

Displays the output tray for the printed job

Delivery

Displays how the printed pages are delivered: face up, face own, face up in reverse order, or face down in reverse order

Collation

Displays whether the printer collates the output.

Shift every # Copies

If you selected **Collate and Shift** in the **Collation** box, define after how many copies the shift is performed.

Staple

Displays whether the output is stapled. Select **Corner**, **Side**, **Saddle** or **Off**.

Staple Position

If you selected **Corner** in the **Staple** box, select the position of the staple: **Left** or **Right**.

Staple Angle

If you selected **Corner** in the **Staple** box, select the angle of the staple: **Vertical**, **Horizontal** or **Slanted**.

Punch

Displays whether the printed pages are punched and with how many holes. Select **2 holes**, **3 holes**, **4 holes** or **Off**.

Fold

Displays whether the sheets are folded and the fold pattern.

Perfect Binder

Displays whether perfect binding is used

If you selected **On** in the **Perfect Binder** box, select the trimming method in the **Trim** box, and type the required values in the **Fore Edge**, **Top Edge**, **Bottom Edge** and **Trim Size** boxes.

Trimmer

Displays whether trimming is used.

If you selected **On** in the **Trimmer** box, type the required value in the **Fore Edge** box.