

Setting up materials

Important: Some of the options described in this topic are not relevant to Workshop in this version of the Prinergy software. Currently only the Substrate resource is available.

In the production process, your print shop uses specific materials (stock, plates, flexo, and so on).

You can set up the details of this material, in order to plan and impose the printing work correctly. These details are stored in a database.

Data that is changed on the fly in a Prinergy job does not affect the records that are stored in the database.

When you add a digital device in Setup, the device's substrates are automatically imported into the Substrate dialog box from the device. The settings of the substrate are read-only and cannot be edited in Setup. However, you can [add](#) a size(s) to the selected substrate and [remove](#) a size(s).