Evaluating a simulation DeviceLink

You can evaluate input tints through the simulation DeviceLink.

1. In the color setup viewer, click the **Simulation** icon .
2. If both the **Curve** and the **DeviceLink** tabs are displayed, click the **DeviceLink** tab.
3. Click **Evaluate**.
4. Do the following:
    - To evaluate tint values through the DeviceLink:
        a. In the **Input Tints** panel, select the **Tint Value Range** of input tint values you wish to evaluate.
        b. Double-click in the first cell of the **Input Tints** table.
        c. Type a Cyan input tint value, or a Red input tint value for an RGB-input DeviceLink.
        d. <tab> to advance and enter a Magenta (or Green) input tint value.
        e. Repeat for other input tint values.
        f. Repeat to enter another set of input tint values.
        g. Terminate input tint entry with <enter>.
        h. In the **Output Tints** panel:
            - select the desired **Tint Value Range** of evaluated output tint values.
            - enter the desired **Tint Precision** of evaluated output tint values.
        i. Click **Evaluate** below the Input Tints table.
    - To copy, paste and evaluate multiple input tints:
        a. Select an array of input values in a spreadsheet or tab-delimited text file.
        b. Copy.
        c. Click in the ColorFlow Evaluate **Input Tints** table.
        d. Select all.
        e. Paste.
        f. Click **Evaluate**.
    - To copy output tints for use by another application:
        a. Click in the **Output Tints** table.
        b. Select all.
        c. Copy.
    - To combine the above two operations:
        a. Select an array of input values in a spreadsheet or tab-delimited text file.
        b. Copy.
        c. In ColorFlow Evaluate, click **Paste - Evaluate - Copy**.
5. Click **Close**.
6. Click **Cancel**.