

Product properties (assembly intent)

Product Name	Use or edit the default name.
Job ID	(Optional) Blank by default; accepts alphabetic characters and numbers
Due Date	This information is currently for your reference only.
Planned Page Count	The product page count, which is initially specified in the product intent, can be updated only by changing the part page counts.
Binding Style	<p>Determines the sequence in which content pages flow through the template pages on the press-run layouts:</p> <ul style="list-style-type: none">• Flat Work (no binding)• Perfect Bound• Saddle Stitched• Come and Go• Cut and Stack• Mixed (more than one binding style)
Planned Colors	Select a predefined common color resource, or type a new descriptor as a placeholder for the actual color.
Comments	Type a note that you or other operators can review and edit.
Parts	Click [+] to add as many parts as needed, which derive their default properties from the product. To display a part and its properties, double-click the part name.
Generate Press Runs	The required number of press runs and impositions is automatically generated, and the run-list pages flow into position according to the template page numbering.