

NexPress

Set up a JMF connection between Prinergy and the NexPress digital press via Setup on Prinergy 9.0.1. Adding NexPress via Prinergy Administrator is no longer supported from Prinergy 9.0.1 and above.

For information about how to set up other types of connections for the NexPress digital press, see the appendix.

- [Connect Prinergy to the NexPress](#)
- [Test the setup](#)

If your Prinergy server is on a network that uses a proxy server, you must bypass the proxy server in order to connect devices to Prinergy.

To do so, go to **Control Panel > Internet Options > Connections > LAN Settings**, and select the the **Bypass proxy server for local addresses** check box.

Note: You can also access this check box from the **Tools** menu in your Internet Explorer browser (**Tools > Internet Options > Connections > LAN Settings**).