

# EFI Fiery

For EFI Fiery qualified with JDF Bi-Directional connectivity please see [New JTE Workflow - JDF /JMF with Device Track and Setup](#).

Set up a JMF connection between Prinergy and the EFI Fiery to submit digital print documents to the Xerox and Konica Minolta presses. There is no JDF editing software for the EFI Fiery digital front end. There is also no default template for EFI installed with Prinergy. You must [create an EFI JDF template](#) using the EFI software.

- [Connect Prinergy to the EFI Fiery](#)
- [Create an EFI Fiery JDF template](#)
- [Test the setup for EFI Fiery](#)

If your Prinergy server is on a network that uses a proxy server, you must bypass the proxy server in order to connect devices to Prinergy.

To do so, go to **Control Panel > Internet Options > Connections > LAN Settings**, and select the the **Bypass proxy server for local addresses** check box.

**Note:** You can also access this check box from the **Tools** menu in your Internet Explorer browser (**Tools > Internet Options > Connections > LAN Settings**).