

Troubleshooting 1

This section describes common problems that you may encounter during the upgrade and their solutions.

- [Running out of space on the Prinergy Server](#)
- [ColorFlowServer fails to install](#)