

Digimaster

Set up an LPR connection between Prinergy and the Digimaster, and create a SmartBoard job ticket.

- [Connect Prinergy to the Digimaster](#)
- [Create a SmartBoard job ticket](#)
- [Holding jobs in the Job Manager queue](#)
- [Test the setup for Digimaster](#)

If your Prinergy server is on a network that uses a proxy server, you must bypass the proxy server in order to connect devices to Prinergy.

To do so, go to **Control Panel > Internet Options > Connections > LAN Settings**, and select the the **Bypass proxy server for local addresses** check box.

Note: You can also access this check box from the **Tools** menu in your Internet Explorer browser (**Tools > Internet Options > Connections > LAN Settings**).