

Adding a press to the ShopMap palette

You can add a press to the **ShopMap** palette by typing information and selecting settings in the New Press dialog box.

In the case of a press that also allows direct printing, such as Heidelberg Direct Imaging, you need to add the device to the **ShopMap** palette both as a press and an output device to have individual configurations.

1. If the **ShopMap** palette is not currently shown, select **Show ShopMap Palette** from the **Window** menu.
2. Click **Materials**.
3. Click the **Press** tab.
4. Click the options arrow on the **ShopMap** palette, and then select **New**.
5. In the **Name** box, type the name of the press.
6. In the **Units** box, select the measurement units to use.
7. In the **Setback** box, type the setback between the substrate and the film or plate, or between the plate and film.
8. In the **Gripper** box, type the gripper margin.
9. In the **Plate bend** box, type the plate bend.
10. In the **First knife** box, type the distance from the edge of the sheet to the edge of the die.
11. Click **Create**.