

Setting bleeds for non-rectangular work

When you snap an artwork to a die station, the Pandora software tries to extract the shape of the artwork from the die station. The initial bleed path of the artwork is offset from the shape of the die station by the amount you specified in the **Preferences > Bleed margins** box. If the software cannot extract the artwork shape, a message appears in the status bar, and Pandora creates a rectangular bleed path.