

Creo Color Server

For [Creo Color Server qualified with JDF Bi-Directional connectivity](#) please see [New JTE Workflow - JDF/JMF with Device Track and Setup](#).

Set up a JMF connection between Prinergy and the Creo Color Server to submit digital print documents to the NexPress, HP, Xerox, and Konica Minolta presses.

The JDF template editing software, Creo Color Server Job Ticket Creator (JTCreator), is available from the Creo Color Server front end.

If your Prinergy server is on a network that uses a proxy server, you must bypass the proxy server in order to connect devices to Prinergy.

To do so, go to **Control Panel > Internet Options > Connections > LAN Settings**, and select the the **Bypass proxy server for local addresses** check box.

Note: You can also access this check box from the **Tools** menu in your Internet Explorer browser (**Tools > Internet Options > Connections > LAN Settings**).