


VPS+ Viewing information related to screening

You can check the average tint value, ruling (frequency) and angle of halftone areas in a rectangular area of the 1-bit TIFF file.

1. On the toolbar, click the eyedropper .
2. In the file, marquee around the area you want to check in the image.
The values of tint average, ruling (frequency) and angle of the selected screened area are displayed on the **Separations** tab of the **Inventory** palette.