

# Adding proofing devices

About connecting Prinergy to Kodak, Matchprint Inkjet (MPI) Controller workstation Kodak Proofing Software (KPS) and specific Epson inkjet proofers, third-party color RIP workstations or Windows PostScript print drivers with PostScript-compatible proofers.

Kodak Prinergy's supported workflows in order of preference:

- Prinergy -> **direct connect** -> **KPS** -> **specific supported Epson SureColor P-series inkjet proofers**.
- Prinergy -> **PDF or TIFF** -> **network shared folders on a 3<sup>rd</sup> party color RIP server** -> printer
- Prinergy -> **PS3 or EPS Raster** -> **Windows PS print driver** -> **PS compatible printer**

**Note:** If your Prinergy server is on a network that uses a proxy server, you must bypass the proxy server in order to connect devices to Prinergy.

To do so, go to **Control Panel > Internet Options > Connections > LAN Settings**, and select the the **Bypass proxy server for local addresses** check box.

**Note:** You can also access this check box from the **Tools** menu in your Internet Explorer browser (**Tools > Internet Options > Connections > LAN Settings**).

- [Setting up a Kodak proofing device](#)
- [Setting up a third-party proofing device](#)