Setting up a third-party proofing device

Set up a non-Kodak proofing device to work with the Prinergy system.

Kodak Prinergy's supported workflows in order of preference:

- Prinergy -> direct connect -> KPS -> specific supported Epson SureColor P-series inkjet proofers.
- Prinergy -> PDF or TIFF -> network shared folders on a third-party color RIP server -> printer
- Prinergy -> PS3 or EPS Raster -> Windows PS print driver -> PS compatible printer
 .
- Supported third-party proofing devices
- Determining if a third-party proofing device can be used with Prinergy
- Configure output to a third-party Color RIP server
- Configure output to a third-party PostScript compatible Printer