## \_suspend measurement

You can suspend measurement at many points in the measurement process. For automated devices, you can suspend measurement before any page measurement. For the X-Rite i1 Pro, you can suspend measurement prior to scanning any row of patches.

- To suspend measurement, click **Suspend**. The suspended measurement data set will not appear in the **Measurements** tab of WorkFlow Editions, since it is incomplete. If you close ColorFlow, your suspended measurement is retained.
- While you are measuring, all measurement data and information are automatically saved. If a system or power failure causes ColorFlow to quit unexpectedly, your measurements are retained as though you suspended the measurement session.
- To resume a suspended measurement, in the **Charts** list, select any chart and then click **Measure**.

ColorFlow will give you the option to resume the suspended measurement, or delete it and start a new measurement.