

Viewing tint values and response of a plate curve

You can view the tint values for the plate line, as well as the uncalibrated and calibrated color responses for the curve.

1. Click the **Plate Curves** tab.
2. In the **Plate Curves** list, click the desired plate curve.
3. In the **Data** panel on the right, click **Plate Curve**.
The **Plate Curve** box appears, showing the shape of the curve and the tint values.
4. To view the response of the curve, click **Plate Response**.