

_adjust displayed color

The color patch displays the output color. If the displayed color does not visually align to the color on your proof or press sheet, you can adjust the displayed color in the color patch:

1. Select the **Adjust Displayed Colors** check box.
2. Use the lightness (L^*) slider and the cast (a^*b^*) selector to change the displayed color to align to the color on your proof or press sheet. This color change does not affect any curves or color control elements. You are only adjusting the displayed color of the patches.
3. To reset the display to the default displayed color, click the **Reset** icon .
4. When you achieve the correct color, clear the **Adjust Displayed Colors** check box.