Plate Remake dialog box

Use the Plate Remake dialog box to remake a plate using the same settings and output device that were used to output the original plate.

Plate ID

Type the identification number of the plate that you want to remake.

Plate Details

When you enter the plate ID, this box is automatically populated with information about the plate—for example, the job, imposition, signature, surface, and separation.

Work Type

If you have Business Link software set up to work with Prinergy, select the reason why you are remaking the plate.

To customize the work type, click **Edit**. For information about customizing the work type, see Customizing work types.