

# Viewing the Failed queue

The **Failed** queue displays jobs on the selected device which failed, were aborted or completed with errors during process or print. Jobs not submitted from the connected Prinergy server appear unavailable (in gray).

Jobs submitted from the connected Prinergy server can be [resubmitted](#), [moved to another connected digital device](#), or [removed](#) from the queue.

The **Failed** queue contains the following information about each of the jobs in the queue:

## Name

Displays the name of the job in the queue

## Failure Time

Displays the date and time the process failed