

# Setting up an RBA rule to import Prinerger layouts

When an operator drops a .jt file into the hot folder connected to this enabled rule, a new Prinerger Workflow job and layout are created by the PLA software. You can then revise marks in PLA without opening the layout in the Pandora software.

1. Start Workshop.
2. In the Job Finder window, select **Tools > Rule Set Manager**.  
**Important:** Do not open Rule Set Manager from a specific Prinerger Workflow job.
3. In the **Rule Set Library** pane, locate the folder you created for storing PLA system-level rule sets (in our example, `PLA System Rule Sets`), and open the **PLA Import Prinerger Layout** rule set.
4. To open the **Create Job** action, double-click the line between the **Select One Item** and **Create Job** actions.
5. Set the following parameters:
  - a. **Job Home Server:** Select the server name from the list of available servers.
  - b. **Job Home Share:** Select the server share location.
  - c. (Optional) **Job Group:** Select the preferred job group.
  - d. **Template Job:** Select the template job to use when creating the layout.
6. Save and enable the rule set.
7. In Job Finder, find `PLATemplateJob` and open it.
8. In Job Manager for `PLATemplateJob`, select **Job > Manage Hot Folders**. Perform the following actions:
  - a. In the Manage Hot Folders window, click **Add**.
  - b. In the Create Hot Folder for Job window, set the hot folder to **Add and Process Files**.
  - c. In the **Workflow Processors** list, locate and select the **PLA Import Prinerger Layout** rule set by selecting `Automation: Enabled Rule Sets\All Jobs\PLA System Rule Sets\PLA Import Prinerger Layout`.

The hot folder is named `PLA Import Prinerger Layout` by default. You can change the name. Or, you can create an external folder on another share to be used as a hot folder, and associate the rule with the external folder. This external folder must be on a share visible to the Prinerger Workflow software. If you created an external hot folder in the Create Hot Folder for Job dialog box, expand **Options**, and select the **Use Custom Location** check box.

For more information about creating hot folders, see the *Prinerger Workflow Workshop User Guide*.