

Deleting a ShopMap resource

A ShopMap resource can be deleted only if it is not used in any current PLA job ticket.

To remove a ShopMap resource that has been used in legacy jobs so that it does not appear in any active job, you must open every job containing that resource and delete it from the job ticket.