

# Deleting a screen color

1. See [Creating process templates](#).
2. In the **Calibration and Screening** section, in the **Screen System** list, select a screen system type.
3. In the **Screen Angle** list, select the screen angle you want to delete.
4. Click **Delete**.