

Job components

In Prinergy, a job is the unit used to organize work. A job typically corresponds with all the components related to a single publication. Every job has a "home server," which is the server where it is stored.

A Prinergy job has the following components:

Component	Description	Location
A job folder named after the job	Contains the files for a job, including the system files that Prinergy generates, such as master PDF files and thumbnails	In the Jobs folder on the job's home server
Input files	Customer files that contain the original information for a printing job, such as PostScript files or imposition plans	Either: • UserDefinedFolders folder in the job folder • Any computer that is visible from the job's home server, such as a file server
Database information	Information about a job, including the: • Location of all files • Status of job elements • History information	An Oracle database on the primary server

Note: Never modify job system files (in the System subfolder in the job folder). If you do, Prinergy may not be able to reference job components.

For more information about job folders, see the *Prinergy Workshop User Guide*.