

Preferences

Control how hot folders work, how long certain data is kept, default settings in Workshop, and many other preferences.

- [RIPs](#)
- [Selecting the default RIP for new jobs](#)
- [Selecting the default copy path for input files](#)
- [About signature ID codes](#)
- [Signature ID Code Editor dialog box](#)
- [Configuring the default signature ID code](#)
- [Non-essential history entries](#)
- [Controlling how long history logs are kept](#)
- [Job folders](#)
- [Defining custom job folders](#)
- [Defining the default job color setup](#)
- [Configuring the behavior of hot folders](#)
- [Controlling the error messages that Prinergy displays](#)
- [Configuring thumbnail compression and resolution](#)
- [Setting approval requirements](#)
- [Controlling revisioned pages for InSite](#)
- [Setting the language of the Preflight+ reports generated from Workshop](#)
- [Plate Remake](#)