

Components of the Archiver system

The Archiver system includes several software and hardware components.

Archiver component	What it is
Archiving station	The Prinerger server that the Archiver software runs on
Archive /Retrieve JTP	Writes jobs or job files onto a tape or disk or returns archived files from a tape or disk to the job's home server. The process is controlled by the Archive process template and the Retrieve process template.
Disk Purge JTP	Removes jobs or job files from the job's home server after verifying that they were archived correctly. The process is controlled by the Purge process template.
Media Manager software	Displays media pools and disk volumes in Workshop so that you view detailed information about media pools and disks, including type, location, amount of free space, and state. Also you can verify access, copy between tapes and disks, and set tapes to read-only status.
Archive Disk Volumes Editor (for archiving to disk)	A tool in Prinerger Administrator that allows you to add, modify, and remove archive disk volumes