

Connect to Ricoh

Set up communication between Prinergy 10.0 and the Ricoh digital front end Total Flow Print Server via [Setup](#). Legacy mode of Adding Connection via Prinergy Administrator is no longer supported in Prinergy 9.0 and above.

Check that Prinergy supports the software version of your digital press front end. See [supported digital presses](#).

Give Prinergy access to the Ricoh digital front end so that Prinergy can track audits. On the Ricoh digital front end, add the user account ARAXI. The default password for the Araxi account is ARAXI.