

Hub-and-spoke workflow with jobs

Your workflow can follow a hub-and-spoke setup where you export an entire job from one Prinergy system and import it into another Prinergy system.

Prerequisite: The .zip file was exported from Prinergy using an ExportAll process template. (If you have a partial job, see [Hub-and-spoke workflow with partial jobs](#) instead.)

1. Create a pre-job.
2. Add a hot folder and associate it with an **ImportAll** process template.
3. Drop the export file into the hot folder.
Prinergy creates a new job named after the .zip filename.
4. Open the job.
Prinergy displays flats as signatures in **Separations** view.
5. Manage colors separations (optional).
6. Proof the imposition by running an imposition output process template.
7. Make plates by running a final output process template.