

Digital Job Ticket Editor—Special Toner tab

Note: Options on this tab may vary depending on the selected digital device. Some of the settings or setting values or this entire tab may not be available. Also, there may be additional settings available for specific devices which are not documented here.

The options in the Digital Job Ticket Editor are based on the capabilities of the selected device. When the Prinergy server connects to a digital device via Setup, the device communicates its capabilities in JMF format. The values for the different parameters are updated in the Setup application per device, and are reflected in the Digital Job Ticket Editor. The default value that was set on the digital device (and can be viewed in Setup) is used as the default value per parameter. If no value was set as default, the Job Ticket Editor displays **Device Default**. This selection can be changed.

When you define settings that are in conflict, these settings are marked with a red line around them, and when you hover above them, a tool tip displays what is wrong with the defined settings. You can also click the **Constraints** tab to see which settings you need to change in order to print the job.

A Special Toner is typically a fifth print station on the digital press. It is normally used to highlight specific areas on the print and/or provide special effects on the printout.

Note: If you make a change in the Setup application while the Digital Job Ticket Editor is open, you must close and reopen the Digital Job Ticket Editor to see the change in the Digital Job Ticket Editor.

Special Toner

Select the name of the special toner.

Note: The **Special Toner** list contains only toners that are available on the selected digital device.

Apply To

Select whether to apply the special toner to a separation.

Separation To Print

Select the separation name used in the document from the list of separation names, or select **Custom** if the separation name does not appear in the list.

Separation Name

If you selected **Custom** in the **Separation To Print** box, type the exact name of the separation to be printed using the special toner.

Plane Priority

Select which spot color has the priority when data is written in the same position for more than one spot colors.

Print Priority

Select **Quality** or **Speed** as your priority of printing.

Page Range

Type the range of pages to be printed.