


Outputting Virtual Proofing files

The Kodak Prinergy Virtual Proofing software, which allows you to soft proof (preview) pages, has been updated to support LPV files.

When outputting LPV pages to the Prinergy Virtual Proofing software, ensure that you select the **Advanced TIFF Tags** check box in the **File Format** section of the proof process template. This enables the Prinergy Virtual Proofing software to automatically sort the separations into versions.

In Prinergy Virtual Proofing software, you can preview each separation, or any combination of separations. The Prinergy Virtual Proofing software also provides a grid showing the separations required for each version. To view the seps per version grid, click the information button on the **Separations** palette.



Prinergy Virtual Proofing software separations palette

The following figure shows the seps per version grid.



The seps per version grid in the Prinergy Virtual Proofing software

For more information on using Prinergy Virtual Proofing software with LPV jobs, see the *Prinergy Virtual Proofing Online Help*.