

Setup

The Setup component is used to manage the equipment, resources, and materials that you need for the digital workflow in Prinerger. You add and remove digital devices (connected to Prinerger via JDF/JMF) in Setup. Setup is used to retrieve the connected device capabilities so that the required settings for a specific job can be defined in the Digital Job Ticket Editor before submitting the job to production.



Use the **Refresh** button, to refresh the information in Setup if changes were made in more than one clients of your Prinerger server at the same time.