

Setting up Sizes

Important: Some of the options described in this topic may not be relevant to Workshop in this version of the Prinergy software.

Sizes are linked to other entities (for example, substrate, media, or page). You can set up the details of the sizes, in order to plan and impose the printing work correctly. These details are stored in a database. Data that is changed on the fly in a Prinergy job does not affect the records that are stored in the database.

Note: When you update a Size that is linked to another entity whose tab is open, you must click



Refresh on the toolbar to update the change in this tab as well.

Currently only the Size resource is available.

- [Setting up a size](#)