

New JTE Workflow - JDF/JMF with Device Track and Setup

KODAK PRINERGY Workflow provides two-way JMF communication via qualified digital front ends (DFEs) for specific digital presses as a newer alternative to the Digital Direct and Digital Submit connectivity methods available previously. This newer type of connectivity allows PRINERGY Workflow to take advantage of devices-specific settings and provides a quicker and more accurate communication between the DFE and PRINERGY Workflow for status and device capabilities.

For information on using and setting up Prinergy Digital connections using Device Track and Setup, please refer to the following help topics in the Prinergy User Guide:

[About using digital printers](#)

[Setup](#)

[Device Track](#)