

Accessing the screen instance file

To use DotShop effectively, you require access to the licensed screen systems and calibration curves on your Prinergy system. These are available in a screen instance file (SIF) that is located on the server and automatically accessed by DotShop on the client computer. You choose from the screen sets and calibration curves available in the SIF file to apply screens to objects and pages in your PDF files.

- [What do screen instances contain?](#)
- [How is the SIF file created?](#)
- [Accessing DotShop Composer on the Prinergy server](#)
- [Where is the SIF file on the server?](#)
- [How do I access the SIF file from the client?](#)