

Delivering screen instances to DotShop

The SIF file in the default %ARAXIHOME%\CreoAraxi\bin folder on the Prinerger server is automatically available to a licensed installation of DotShop on the Prinerger client computer. There is no need for the user to mount a server or copy the file.