

Files list

The **Files** list displays information about the input files and pages, including the number of times each page appears on a press run in the job.

File Name	Displays the name of each file or file placeholder that you add to the job. Multi-page files can be expanded to show their list of sequentially numbered pages. This page number is appended to the File Name in the Pages List.
Count	A dynamically updated value appears beside each page to indicate the number of times that the page appears on a press run in the job. To sort the values in the Count column in ascending (zero to highest value) or descending (highest value to zero), click the column heading. This helps you quickly identify items that haven't been placed.
Pages	Displays the number of pages that each file contains.
Trim	Displays the dimensions of the PDF page or placeholder page. If a PDF input file does not specify the trim box size, the bleed box or media box size is used.
Colors	Displays the colors that are specified in the PDF input file.
[+] and [-]	Click [+] and [-] to locate and add or remove selected files.