


Pages workspace

Use the workspace in the **Pages** view to check the alignment of the content within the trim box. You can reposition the content by dragging the page, or fine-tune the positioning by directly editing the dimension text boxes.

- To display a page in the workspace, select it in the **Pages List**. Selecting a page also displays its settings in the **Properties** pane.
- To quickly select all pages, all odd or even pages, or a range of pages in the **Pages List**, right-click a product or part, and select an option.
- To control which details are displayed in the workspace, use the [View menu](#) and the workspace toolbar.

Page trims		You can view the following trims: • Trim box: Dark blue rectangle that initially represents the PDF file or the default page size for a placeholder page. After the run-list page is placed on a press run, the trim box is derived from the template page. • Bleed box: Red rectangle that is relative to the trim box • Page size: Green lines that show a PDF page relative to the trim box, adjusted when you reposition, rotate, or scale the PDF run-list page • Planned page size box: Pink rectangle that appears only if specified for an assembly's product intent
Select		For pages that are already assigned to a layout, use this tool to select and drag the trim guides to reposition the content within the trim box.
Rotate		Rotates the content of the previewed page in 90-degree increments without changing the template-page orientation
Pan		Moves your view of the workspace
Zoom		Click the object or general area that you want to inspect more closely, or drag a marquee around a specific area.
Show Page Previews		Display a preview of all page content.
Show Dimensions		Displays the page dimensions, including any distances between the template-page trim box and the PDF content trim box. You must select View > Show Trim Box to use this option.

Page preview navigators	 The image shows a small UI component for page navigation. It consists of a light gray background with a thin border. At the top, there are two small blue triangles pointing left and right, followed by a white rectangular box containing the number '1'. To the right of the box is a small blue vertical bar, and further right is another white rectangular box containing the number '1'.	Select a page in the Pages List to display, and then use the arrow keys to scroll through the other pages in the current list. The text box displays the run-list number of the currently previewed page, followed by the total number of pages in the current list. To jump to a specific page within the current list, type its run-list number in the box.
--	---	---