

Turning off punch marks in the output

Specify a location for the punch mark that is beyond the edge of the press sheet. By default, a punch mark appears centered on the bottom edge of the press sheet. Use this procedure if you do not want the punch mark to appear on the press sheet, or to include an amount for setback or plate bend.

1. In the Preferences dialog box, load the profile that you want to use for printing without punch marks.
2. On the **Output** tab in the Preferences dialog box, clear the **Display punch mark** check box.
The punch mark will not preview or print in job layouts while this check box is cleared.
3. To permanently turn punch marks off in all press runs that you print using this profile, save the currently loaded profile.