

Defining a step for the repeated element

1. On the **S&R** tab of the **Info** palette, in the **Step** box, type the width offset (in mm) of the element from one row or column to another and press Enter.
2. From the **in** menu, make one of the following selections:
 - For workflows that define the around-the-drum direction as the X dimension (rows), select whether to step the elements in **All Rows**, only in **Even Rows**, or only in **Odd Rows**.
 - For workflows that define the around-the-drum direction as the Y dimension (columns), select whether to step the elements in **All Columns**, only in **Even Columns**, or only in **Odd Columns**.